

Y-motor Changing Process

Expert/Expert II Expert LX /Expert II LX

Revision History :


Version	Date	Page	CONTENTS
1.0	May 24, 2014		First release
2.0	Sept. 16, 2015		Add Expert II, Expert II LX

How to replace Y-Motor


Tools Required:

- Allen Wrench

1. Unplug cable from motor.



2. Use Allen Wrench to loose four screws.



3. Change Y motor.

